

5. It is the duty of the authorized person to take prior permission of the prescribed authority to close down the facility.
6. The authorization is granted for generation of Bio-Medical Waste (BMW) in waste categories and quantities listed here in below :

Sr. No.	Category	Quantity	UOM	Treatment & Disposal
1	Cat-1 Human Anatomical waste	5.0	Kg/M	Treatment & disposal through CBMWTSDF i.e. M/s. Passco Environmental Solution Pvt Ltd Pune
2	Cat-3 Microbiology Waste	0.0	Kg/M	
3	Cat-4 Waste Of Sharps	8.0	Kg/M	
4	Cat-5 Discarded Medicines And Cytotoxic Drugs	0.5	Kg/M	
5	Cat-6 Solid waste	7.0	Kg/M	
6	Cat-7 Solid waste	7.0	Kg/M	
7	Cat-8 Liquid Waste	0.0	Kg/M	

- \*The occupier shall join the common BMW Treatment & Disposal Facility authorized by MPCB in Pune i.e. **M/s. Passco Environmental Solution Pvt Ltd Pune** shall send the BMW regularly to CBMWTSDF for its scientific treatment & Disposal.
7. The liquid/solid waste generated from the treatment activity (from laboratory and washing, cleaning, housekeeping and disinfecting activities) shall be treated suitably by providing effluent treatment facility to conform the standards prescribed in Schedule V of said Rules and the Environment (Protection) Act, 1986.
  8.
    - i) The daily quantity of tread effluent shall not exceed Nil.
    - ii) The daily quantity of tread effluent Shall not exceed 0.5 M3
  9. (i) BMW shall be treated and disposed of in accordance with Schedule I; and in compliance with the standards prescribed in Schedule V of said Rules.
    - (ii) You shall setup requisite BMW treatment facilities like incinerator, autoclave / Microwave, shredder etc., at the disposal side in accordance with the BMW rules. You shall disposed of the duly treated BMW and incineration ash in secured land fill site at your own premises / at MSW secured land fill site of Municipal Council authorized by MPCB and duly earmarked for disposal of treated BMW / at common H.W. treatment & disposal facility setup as per the Hazardous Waste (M & H) Rules, 1989 as amended and authorized by MPCB.
  9. (i) BMW shall not be mixed with other wastes or reused, recycled or sold in any form.

- (ii) BMW shall be segregated into containers / bags at the point of generation in accordance with Schedule-II prior to storage, treatment and disposal. The containers shall be labeled according to Schedule III.
  - (iii) If a container containing BMW is to be transported from the premises where BMW is generated to any waste treatment facility outside the premises, the container shall, apart from the Label prescribed in Schedule III, also carry information prescribed in Schedule IV and shall be transported by authorized Transporter only.
  - (iv) Notwithstanding anything contained in the Motor Vehicles Act, 1988 or Rules there under, BMW shall be transported only in such vehicle as may be authorized for the purpose by the competent authority as specified by the Government.
  - (v) No untreated BMW shall be kept stored beyond a period of 48 hours.
10. Standards for waste autoclaving;
11. The autoclave should be dedicated for the purposes of disinfecting and treating bio-medical waste,
12. When operating a gravity flow autoclave, medical waste shall be Subjected to a temperature of not less than 121 C° and pressure of 15 pounds per Square inch (psi) for an autoclave residence time of not less than 60 minutes; a temperature of not less than 135 C° and a pressure of 31 psi for an autoclave residence time of not less than 45 minutes; or
- (ii) a temperature of not less than 149 C° and a pressure of 52 psi for an autoclave residence time of not less than 30 minutes.
  - (iii) When operating a vacuum autoclave, medical waste shall be subjected to a minimum of one pre-vacuum pulse to purge the autoclave of all air. The waste shall be subjected to the following, a temperature of not less than 121 C° and a pressure of 15 psi for an autoclave residence time of not less than 45 minutes; or
  - (iv) a temperature of not less than 135 C° and a pressure of 31 psi for an autoclave residence time of not less than 30 minutes; or
- (VI) Medical waste shall not be considered properly treated unless the time, temperature and pressure indicators indicate that the required time, temperature and pressure were reached during the autoclave process. If for any reasons, time temperature or pressure indicates that the required temperature, pressure or residence time was not reached, the entire load of medical waste must be autoclaved again until the proper temperature, pressure and residence time were achieved.
- (IV) *Recording of operational parameters.*- Each autoclave shall have graphic or computer recording devices which will automatically and continuously monitor and record dates, time of day, load identification number and operating parameters throughout the entire length of the autoclave cycle.
- (V) *Validation test: Spore testing.* - The autoclave should completely and consistently kill the approved biological indicator at the maximum design capacity of each autoclave unit. Biological indicator for autoclave shall be Bacillus stearothermophilus spores using vials or spore strips, with at least 1x 10<sup>4</sup> spores per milliliter. Under no circumstances will an autoclave have minimum operation parameters less than a residence time of 30 minutes, regardless of temperature and pressure, a temperature less than 121 C° or a pressure, less than 15 psi.
- (VI) Routine Test.—A chemical indicator strip/tape that changes color when a certain temperature is reached can be used to verify that a specific temperature has been achieved. It may be necessary to